

User instructions:**1. Diluting the Solution:**

First make sure you have a solution for the syringes diluted to the required concentration

2. Filling the syringe (Part One):

With the plunger firmly seated in the bottom position (plug down) insert the syringe tip only into the solution. Draw in 20 ml (or if recommended, another quantity). It is often found easier to turn the plunger a 1/16 turn clockwise and draw liquid into the barrel until resistance is met (The built in resistance alerts you that 20 ml of liquid has been drawn into the syringe)

3. Filling the syringe(Part Two):

Once the resistance has been met, rotate the plunger back to re-align the graduations. Remove the syringe from the solution and fill the remainder of the syringe with air.

4. Locking the syringe:

Twist the plunger clockwise with respect to the syringe, temporarily lock the plunger to the barrel.

5. Inserting the syringe tip into the tree:

Insert the syringe tip into the 5 mm pre-drilled hole in the avocado tree limb. Screw the WHOLE syringe unit clockwise to ensure a firm and secure fit. Note: the syringe tip should be at the bottom and pointing slightly downwards.

6. Unlocking the syringe:

Unlock the syringe sleeve with a quarter turn anti-clockwise with respect to the syringe body.

7. Releasing the solution:

Gently depress the plunger down to create air pressure on the solution, while maintaining the syringe in its original position.

8. Locking the syringe:

When a firm pressure is achieved (do not force this) lock the syringe plunger by turning the plunger a quarter turn clockwise.

9. Absorption of the solution:

The tree should absorb the solution within 6—8 hours. If this does not happen, unlock the plunger and increase the pressure on the liquid and re-lock the plunger. If possible, leave the syringe in the tree for 24 hours.

10. Removing the syringe:

To remove the syringe, simply unwind the whole unit from the tree.

11. Cleaning the syringe:

To clean the syringe, take the unit apart by unscrewing the cap at the top of the barrel. Wash all parts in warm, soapy water.

12. Looking after the syringe:

It is recommended that a light coating of silicone lubricant be applied to the washer and internal barrel surface before storing away from sunlight. Aongatete have the spray available to purchase.

Please contact us if we can assist with products or information at:

**AONGATETE COOLSTORES
LTD**

Phone: (07) 552 0916

Fax: (07) 552 0671

visit us at

2380 Main Road

RD2 Katikati 3178

NEW ZEALAND

or email us on

enquiry@coolstore.co.nz

or visit our Website:

www.coolstore.co.nz